

How to Sew a 2 step French Seam to Prevent Frayed Edges

Judy Stinson

Step 1- with RIGHT side of fabric on outside,
sew the side seams with a zig-zag stitch
VERY close to the edge of fabric



Step 2 turn inside out and sew side seam with a straight stitch. Use normal seam allowance width (3/8-1/2 inch) which will “catch” the raw seam inside.



Turn inside out for a professionally finished bag.